Display Units (Altitude, Speed, Distance)

Stratos Tactical GPS Altimeter · https://deepandsteep.io/knowledge/stratos-display-units/

Last updated November 15, 2026

You can choose the units the Stratos uses for altitude, distance, vertical speed, ground speed and coordinates.

Changing the Units

1. From the Home screen, press the center button, and select Settings → Units.
2. Select a setting. Each press of the center button changes the setting to the next unit.

[Stratos Units menu showing the Altitude, Distance, Asc Vspd, FF Vspd, CP Vspd, Gspd and Coords settings]

Units menu

You can also set the units with the Deep and Steep app. See Deep and Steep App Overview.

Units Settings

Setting	Options	Default
Altitude	ft, m	ft
Distance	nm, mi, km	nm
Asc Vspd	fpm, m/s	fpm
FF Vspd	fpm, fps, mph, m/s, kph	mph
CP Vspd	fpm, fps, mph, m/s, kph	fps
Gspd	kts, mph, kph	kts
Coords	MGRS, Lat/Lon	MGRS