Freefall Speed

Stratos Tactical GPS Altimeter · https://deepandsteep.io/knowledge/stratos-freefall-speed/

Last updated November 15, 2026

You can change the speed the Stratos uses to tell freefall from canopy flight. Most jumpers never need to change it; the Slow option is for slow wingsuit flights.

Changing the Freefall Speed

1. From the Home screen, press the center button, and select Settings.
2. Select **FF Speed**. Each press of the center button changes the setting between Normal and Slow.

[Stratos Settings menu with FF Speed: Normal selected]

Settings menu

Freefall Speed Settings

- **Normal**: Sets the Stratos to detect freefall above about 80 mph (130 km/h). This is the default.
- **Slow**: Sets the Stratos to detect freefall above about 30 mph (47 km/h). Use this option only for slow wingsuit flights.

Caution

With the Slow option and a small, fast canopy, the Stratos can record the whole jump as freefall. Set **FF Speed** back to Normal after your wingsuit jumps.