Stratos Menu Map

Stratos Tactical GPS Altimeter · https://deepandsteep.io/knowledge/stratos-menu-map/

Last updated November 15, 2026

Every menu item on the Stratos, under the main screen whose menu holds it, with links to the articles that explain it. A link on a menu covers the items under it.

Home Menu

Home screen, **center** button:

- Light — Display Light (Night Jumps)
- System
  - App Connect — App Connect
  - USB Connect — Logbook and Recent Jumps, GPS Tracks and Recording Options
  - Shutdown — Stratos Tactical GPS Altimeter Overview
  - GPS
    - GPS Reset — GPS Tracks and Recording Options
    - Delete All Tracks — GPS Tracks and Recording Options
    - Lock Recording / Unlock Recording — GPS Recording Lock (OpSec)
  - Misc
    - Fix Marker List — GPS Markers – DIP and HARP
    - BLE Reset — Wireless Connectivity and Saved Devices
    - ALS — Display Light (Night Jumps)
  - Firmware — Stratos Firmware Update
- Settings

    - Altitude Display — Altitude Display Configuration
        - Mode
        - Setup Display
        - DIP Glide Altitude
    - Units — Display Units (Altitude, Speed, Distance)
        - Altitude
        - Distance
        - Asc Vspd
        - FF Vspd
        - CP Vspd
        - Gspd
        - Coords
    - FF Speed — Freefall Speed
    - Date & Time — Time and Date
        - Hour Type
        - Set Time
        - Set Date

- Training — Training Aides and Lockdown Mode
    - Lockdown
    - Freefall Demo

- Logbook
    - Total Jumps — Jump Number and Jump Counter
    - Zero Counter — Jump Number and Jump Counter
    - Delete Last Jump — Logbook and Recent Jumps
    - Delete Jump # — Logbook and Recent Jumps

- Device Info — Stratos Tactical GPS Altimeter Overview

Logbook Screen

Logbook screen, **center** button:

- Recent Jumps — Logbook and Recent Jumps

Connect Menu

Connect screen, **center** button:

- -new- — Wireless Connectivity and Saved Devices
  - Search HUD — Heads Up Display (HUD) Connect
  - Search Soundlink — Soundlink Wireless Connect (Bluetooth)
  - Search GServe — Stratos G-Serve (GPS Server)
- A saved HUD
  - Connect / Disconnect — Wireless Connectivity and Saved Devices
  - Remove — Wireless Connectivity and Saved Devices
  - Top, Ctr, Btm — Heads Up Display (HUD) Connect
- A saved Soundlink
  - Connect / Disconnect — Wireless Connectivity and Saved Devices
  - Remove — Wireless Connectivity and Saved Devices
  - FF Alarms — Soundlink Alarms and Announcements
    - Save
    - FF #
    - Edit
  - CP Alarms — Soundlink Alarms and Announcements
    - Save
    - CP #
    - Edit

    - Announce — Soundlink Alarms and Announcements
        - Save
        - Type
        - Mode
        - Frequency
    - Settings
        - Save
        - FF Vol — Soundlink Settings
        - CP Vol — Soundlink Settings
        - Tone Pitch — Soundlink Settings
        - CP Open
        - Sync Alti Info

- A saved G-Serve
    - Connect / Disconnect — Wireless Connectivity and Saved Devices
    - Remove — Wireless Connectivity and Saved Devices
- Auto — Wireless Connectivity and Saved Devices
- GPS Stream — GPS Stream (ATAK)

GPS Menu

GPS screen, **center** button:

- Markers List — GPS Markers – DIP and HARP
- Add Marker — GPS Markers – DIP and HARP
    - Save
    - Coords
    - Name
    - Mark Here

    - Delete Marker
    - Active DIP
    - Active HARP
- M. Declination — Magnetic Declination
- Rec — GPS Tracks and Recording Options

Altitude Menu

Altitude screen, **center** button:

- DIP Offset — DIP Offsets: Altitude and Pressure (QFE)
- Clear Offsets — DIP Offsets: Altitude and Pressure (QFE)
- Cur. mb — DIP Offsets: Altitude and Pressure (QFE)
- DIP Pressure — DIP Offsets: Altitude and Pressure (QFE)